



*sync*AXIS control Viewer

*sync*AXIS control **V1.8.0**

SCANLAB GmbH
Siemensstr. 2a
82178 Puchheim
Germany

Tel.+49 (89) 800 746-0
Fax+49 (89) 800 746-199

info@scanlab.de
www.scanlab.de

© SCANLAB GmbH
(Doc. Rev. 1.5.0 en-US - 2022-08-26)

SCANLAB GmbH reserves the right to change the information in this document without notice.

No part of this document may be processed, reproduced or distributed in any form (photocopy, print, microfilm or by any other means), electronic or mechanical, for any purpose without the written permission of SCANLAB GmbH.

All mentioned trademarks are hereby acknowledged as properties of their respective owners.



Contents

1	About this Manual	4
1.1	Related Documents	4
1.2	Manufacturer	4
1.3	Glossary	5
2	syncAXIS control Viewer	6
2.1	Intended Use	6
2.2	System Requirements	6
2.3	Installing and Starting syncAXIS control Viewer	7
2.4	Loading a Simulation File	8
2.5	GUI – Main Window	9
2.5.1	Zooming and Scaling	10
2.5.2	Limit Value Exceedances ("Limits Breached")	10
2.5.3	Color Map	12
2.5.4	Toolbar	13
2.5.5	Controls	15
2.5.6	Dialog "Loading Options"	18
2.6	syncAXIS control Viewer Basic Procedure (Principle of Use)	20
3	Change Index	22

1 About this Manual

This manual describes the software
SCANLAB **syncAXIS control Viewer**.

Notice!

Carefully read the document “syncAXIS control Software License Agreement” before installing and using syncAXIS control. This agreement defines matters such as terms of usage, warranty information and liability disclaimers. If you have questions, simply contact SCANLAB.



Caution!

Read and observe all safety instructions in this manual!

SCANLAB accepts no liability for damages or consequential losses resulting from non-observance of this manual, in particular the safety instructions contained herein.

1.1 Related Documents

- RTC6 Manual
- “syncAXIS control-DLL – Application Programming Interface” Manual
- “Installation of SCANLAB XL SCAN Components and Initial Operation of the XL SCAN System” Manual
- “syncAXIS control Viewer” Manual
- “syncAXIS control Configurator” Manual
- “syncAXIS control Master-Slave-Synchronizer” Manual

1.2 Manufacturer

SCANLAB GmbH
Siemensstr. 2a
82178 Puchheim
Germany
Tel. +49 (89) 800 746-0
Fax +49 (89) 800 746-199
info@scanlab.de
www.scanlab.de

1.3 Glossary

GUI	Graphical User Interface.
syncAXIS control instance	A software object which is created in the PC-RAM when a valid <code>syncAXISConfig.xml</code> is called by a syncAXIS control-based user program.
<code>syncAXISConfig.xml</code>	XML configuration file. Although the file name can be freely chosen, it is denominated as " <code>syncAXISConfig.xml</code> " throughout this document. The complete tag descriptions can be found in " syncAXIS control-DLL – Application Programming Interface " Manual, Chapter 13 " Appendix F: Reference of syncAXISConfig.xml Tags ", page 357.
Simulation File	See " syncAXIS control-DLL – Application Programming Interface " Manual, Chapter 2.5 " About Simulation Mode and Simulation Files ", page 33.
XML configuration file	<p><code>syncAXISConfig.xml</code>. Text file in XML format. Contains the parameter values ("configuration") with which a syncAXIScontrol-DLL-based user program initializes the syncAXIS control instance, see "syncAXIS control-DLL – Application Programming Interface" Manual, Chapter 2.4 "About Initializing syncAXIS control-based User Programs", page 26.</p> <p>It consist of several sections, for example, <code>RTCCConfig</code> and <code>LaserConfig</code>.</p> <p>Example for <code>RTCCConfig</code>:</p> <pre><cfg:RTCCConfig> <cfg:BoardIdentificationMethod>UseFirstFound </cfg:BoardIdentificationMethod> <cfg:ProgramFileDirectory /> <cfg:Boards> <cfg:RTC6> <cfg:SerialNumberSerialNumber>0</cfg:SerialNumber> <cfg:HeadA>ScanDevice1</cfg:HeadA> <cfg:HeadB>Stage1</cfg:HeadB> </cfg:RTC6> </cfg:Boards> </cfg:RTCCConfig></pre> <p>For further information refer to "syncAXIS control-DLL – Application Programming Interface" Manual,</p> <ul style="list-style-type: none"> • Chapter 2.2.3 "Configuring Safe syncAXIS control Instances", page 20 • Chapter 13 "Appendix F: Reference of syncAXISConfig.xml Tags", page 357

2 syncAXIS control Viewer

2.1 Intended Use

syncAXIS control Viewer is a software⁽¹⁾ (with GUI, Figure 1, page 9) for visualizing unmodified Simulation Files which have been generated by a syncAXIScontrol-DLL-based user program.

One or even several Simulation Files at once can be imported. Several plots are available. Depending on the plot, some of the data displayed originate directly (unprocessed) from the specified Simulation File, others are derived from calculations in syncAXIS control Viewer.

syncAXIS control Viewer is able to indicate positioning stage and scan head limit value exceedances in the plots, see Chapter 2.5.2 "Limit Value Exceedances ("Limits Breached")", page 10.

Notice!

syncAXIS control Viewer *does not* provide any support for interpreting the content of the plots. This requires exclusively the expertise of the user and is his sole responsibility.

2.2 System Requirements

As with syncAXIScontrol-DLL.

(1) syncAXIScontrol_Viewer.exe is designed to be executed as 32-bit application on MS Windows 32-bit variants and as 64-bit application on MS Windows 64-bit variants.

2.3 Installing and Starting syncAXIS control Viewer

(1) Copy all delivered files to a target folder on your system.

(2) Do one of the following:

- Start `syncAXIScontrol_Viewer.exe` in Explorer.
- Carry out a command line call, see [Command line call syntax](#).
`syncAXIS control Viewer GUI` opens.

Command line call syntax


`syncAXIScontrol_Viewer.exe [OPTION] , , , [FILE] , , ,`

Arguments		
[OPTION]	Not mandatory.	
	<code>/?</code>	Opens a dialog which shows help information.
	<code>-a</code>	Read in positions are displayed more accurately. Files are read in slower.
	<code>--accurate-limits</code>	For files which are not read in completely due to ' <code>-r</code> ': Improves the limits. Example: <code>-r 5 -l</code> .
	<code>--accurate-position</code>	Like <code>-a</code> .
	<code>-h</code>	Like <code>/?</code> .
	<code>--help</code>	Like <code>/?</code> .
	<code>-l</code>	Like <code>--accurate-limits</code> .
	<code>-r</code>	Lines are skipped at the specified interval. Files are read in faster. Example: <code>-r 5</code> only reads every 5 th line.
	<code>--read-each</code>	Like <code>-r</code> .
[FILE]	Not mandatory.	
		Multiple files can be read in at the start. Example: <code>syncAXIScontrol_Viewer.exe file1.txt file2.txt file3.txt</code> . Files after the first are appended.
		The command line argument is applied to all files. Example: <code>-r 10 file1.txt file2.txt file2.txt</code> causes all 3 files read in with instruction 'every 10 th line only'.

2.4 Loading a **Simulation File**

- Click **File > Open** and choose your desired **Simulation File**.
See **Dialog “Loading Options”**.
Alternatively you can drag a **Simulation File** in the program window.
Note:
Before loading, **syncAXIS control Viewer** checks how much space is available in the working memory. If this is not sufficient for the complete **Simulation File**, the program loads only up to a certain time index. A corresponding message appears in the main window.

2.5 GUI – Main Window



syncAXIS control Viewer main window: areas.

2.5.1 Zooming and Scaling

- To zoom in a whole diagram:
Use mouse wheel.
- To zoom specific areas:
Click and hold left mouse button and mark the specific area. **syncAXIS control Viewer** zooms in the selected area.
Note: If necessary, the scale division is changed (not in Data type Position 2D).
- To reset the zoom:
Click **Fit screen**

2.5.2 Limit Value Exceedances ("Limits Breached")

From the currently loaded **Simulation File**, **syncAXIS control Viewer** reads out:

- working field size, max. velocity, max. acceleration and max. jerk of the positioning stage⁽¹⁾

If the working field size is not specified in the configuration:


- the value is taken from the correction file specified in **DefaultCorrectionFile**
 - If this is not successful, 54 mm × 54 mm is used⁽²⁾.

syncAXIS control Viewer uses the currently loaded **Simulation File** to indicate exceedances of positioning stage working field boundaries and dynamic limits as well as scan head working field boundaries in the plots. Affected curve sections are drawn in *orange* and corresponding information is shown in the status bar. **Figure 2, page 11** shows an example of limit value exceedances.

With limit value exceedances, the list

Limits breached appears on the right hand side of the status bar.

- Click **Limits breached**. All matching limit value exceedances are shown:.



In this example, the x and y position values are exceeded. In general, following options are available, depending of the exceeded limits:


- Position scanner X
- Position scanner Y
- Position stage X
- Position stage Y

If no limits are exceeded, the box **Limits breached** is not shown.

- Tip: To determine "where" in the marking result the problem would occur, set:
 - **Data type: Position 2D**
 - **Device type: Combined** and then click
 - **Isometric 2D**

(1) See "**syncAXIS control-DLL – Application Programming Interface**" Manual.

(2) A corresponding message opens.
Furthermore, subsequently the status bar shows
"Correction File: Not found - using default limits".




syncAXIS control Viewer: Display of limit value exceedances.

2.5.3 Color Map






It is possible to overlay the displayed curves with a color map. This color map shows selected values colored, see [Figure 3, page 12](#). Depending on the height of the value, another color is displayed. Note the color scale on the right.






- Click **Color Map** in the **Toolbar** and choose the value to be displayed in color. For each selection, the norm is displayed. It can be shown (each for scanner and stage):
 - position
 - velocity
 - acceleration
 - jerk
 and the Job Function.
- Click the color scale on the right, hold the mouse button and drag the mouse to adjust the scale.
- Choose **Limits breached** to end the colored display.



Display of a color map of the scanner (Norm position scanner).

2.5.4 Toolbar

	<p>File</p> <ul style="list-style-type: none"> To open a Simulation File (*.txt). For more details, see Chapter 2.5.6 "Dialog "Loading Options"", page 18. To export header(s) of the currently loaded Simulation File(s) in XML format.
	<p>Fit screen</p> <p>To reset the zoom factor or the scaling and to adjust the size of the diagram to the screen.</p>
	<p>Isometric 2D</p> <p>Only appears, when diagram type Position 2D is selected (for example, if circles are not represented as circles, but as ellipses due to different scale divisions): Fits the entire diagram into the diagram area. Thereby, the same scale division is applied to the X-axis and Y-axis.</p>
	<p>Tracker options</p> <p>To open the Tracker settings.</p> <ul style="list-style-type: none"> Choose the information to show in the Tracker when moving the cursor over a curve or clear Enable Tracker. The Tracker is not shown anymore. <div data-bbox="603 1160 1157 1444"> <p>Items to display on tracker</p> <ul style="list-style-type: none"> <input checked="" type="checkbox"/> Path Velocity <input checked="" type="checkbox"/> Active Channel 1 <input checked="" type="checkbox"/> Active Channel 2 <input checked="" type="checkbox"/> Laser On <input checked="" type="checkbox"/> Job function </div> <p><input checked="" type="checkbox"/> Enable Tracker</p> <p>With options chosen as shown above, the Tracker shows following information when moving over a curve:</p> <div data-bbox="582 1592 1316 1937">  <p>Tracker</p> </div>

 Scan field limits	<h3>Scan field limits</h3> <p>To set the limits of the working field. The default values are the limits indicated in the Simulation File (*.txt).</p> <ul style="list-style-type: none">Type in the desired values and click Apply. <div><div>X Axis Minimum: <input type="text" value="-15"/> mm</div><div>X Axis Maximum: <input type="text" value="15"/> mm</div><div>Y Axis Minimum: <input type="text" value="-15"/> mm</div><div>Y Axis Maximum: <input type="text" value="15"/> mm</div><div>Apply</div></div>
 Color Map	<h3>Color Map</h3> <p>To display of color maps of several values, see "Color Map", page 12.</p> <ul style="list-style-type: none">Select the norm to display.
 Config Info	<h3>Config Info</h3> <p>To display configuration information.</p>
 Guides	<h3>Guides</h3> <p>To show/delete (not: hide) guides.</p> <ul style="list-style-type: none">Click Guides. The configuration panel appears in the status bar. <div><div><div><input checked="" type="checkbox"/> Horz</div><div>guide1: <input type="text" value="-14.88"/></div><div>guide2: <input type="text" value="13.59"/></div><div>diff: <input type="text" value="28.47"/> mm</div></div><div><div><input checked="" type="checkbox"/> Vert</div><div>guide1: <input type="text" value="0.09"/></div><div>guide2: <input type="text" value="0.29"/></div><div>diff: <input type="text" value="0.20"/> s</div></div></div> <ul style="list-style-type: none">Choose, if horizontal or vertical guides (or both) should appear.Click the guide, hold the left mouse button and drag it to the desired position. Alternatively you can enter exact values for each guide in the configuration panel. The distance between both guides is shown on the right hand side.
 About	<h3>About</h3> <p>To show the version number and manufacturer information.</p>

2.5.5 Controls

<p>Data Type</p> <p><input checked="" type="radio"/> Position</p> <p><input type="radio"/> Position 2D</p> <p><input type="radio"/> Velocity</p> <p><input type="radio"/> Acceleration</p> <p><input type="radio"/> Jerk</p> <p><input type="radio"/> None</p>	<p>Group 'Data type'</p> <p>For selecting the diagram type (plot) to be shown in the diagram area. The selected option is used as diagram title (4 in Figure 1).</p> <p>Position x,y [mm] vs. Time [s]</p> <p>Position 2D y [mm] vs. x [mm]</p> <p>Velocity vx, vy [m/s] vs. Time [s] (laser spot speed; square root of $(v_x^2 + v_y^2)$)</p> <p>Acceleration ax, ay [m/s²] vs. Time [s]</p> <p>Jerk jx, jy [m/s²] vs. Time [s]</p> <p>None None of the above diagram types. Nevertheless, Active Channel curves are shown, if these are selected.</p>
<p>Channel type</p> <p><input checked="" type="checkbox"/> Active channel 1 (*)</p> <p><input checked="" type="checkbox"/> Active channel 2 (*)</p> <p>(*) Actual Active channel names are shown here after the Simulation File has been loaded.</p>	<p>Group 'Channel type'</p> <p>To select which Active Channel curves are to be shown in the diagram area.</p> <ul style="list-style-type: none"> Disabled, if Position 2D is selected. Even available, if None is selected. The screenshot on the left shows the check box labels immediately after <code>syncAXIScontrol_Viewer.exe</code> start. After the Simulation File has been loaded, the labels are changed according to the Active Channels entered there. That is, for example, "Active Channel 1" is changed to "Analog out 2" and "Active Channel 2" is changed to "Spot distance". <p>Active channel 1 (for example, Analog out 2) If the check box is selected, the corresponding curve is shown in the diagram. The curve is shown in addition to other curves.</p> <p>Active channel 2 (for example, Spot distance) See Active channel 1.</p>

<div>Axis Type</div> <div> <input checked="" type="radio"/> X <input type="radio"/> Y <input type="radio"/> X/Y <input type="radio"/> Absolute </div>	Group 'Axis type' To select which axes are to be shown as curves.
	X Shows curve of x values.
	Y Shows curve of y values.
	X/Y Shows curves of both axes.
	Absolute Shows the absolute value of the X/Y vector.
<div>Device type</div> <div> <input checked="" type="radio"/> Scanner <input type="radio"/> Stage <input type="radio"/> Combined </div>	Group 'Device type' To select which motion portions (scan head and/or positioning stage) are to be included in the shown curves.
	Scanner Shown curves shall include scan head portions only.
	Stage Shown curves shall include positioning stage portions only.
<div>Scan head</div> <div>1 ▼</div>	Group 'Scan head' To select from which scan head the data to be shown as curves (on multi head systems).
	Click the drop down list and select your desired scan head number. The number of entries can vary here. For default, data of scan head 1 is shown after loading a Simulation File .
<div>Segment type</div> <div> <input checked="" type="radio"/> Show jumps <input type="radio"/> Hide jumps <input type="radio"/> Visualize jumps </div>	Group 'Segment type' To select which vectors (mark vectors, jump vectors) are to be included in the shown curves.
	Show jumps Shown curves shall include mark vectors and jump vectors. Each curve is uniformly colored.
	Hide jumps Shown curves shall include mark vectors only (no jump vectors). Each curve is uniformly colored.
	Visualize jumps Jump vectors in all curves are highlighted (grey).

Meta data

173859 data points

Min(x) : -34.7 mm

Max(x) : 40.9 mm

Min(y) : -34 mm

Max(y) : 40.6 mm

Spot distance : 5 μ m

Group 'Met data'

Shows read-only information on imported data records, extrema and laser spot distance.

*Important: all data shown here base on the selected import options, see [Chapter 2.5.6 "Dialog "Loading Options""](#), page 18 as well as **Cancel**. Actual values may therefore differ (for example, the number of data points does not necessarily have to be the total number of lines in the [Simulation File](#))!*

<n> data points: number of [Simulation File](#) lines that has been imported to [syncAXIS control Viewer](#).

Extrema (always 4 lines): depending on the current diagram type, up to 4 values (including unit) are shown.

Extrema Available with diagram type

Min(x) **Position, Position 2D**

Max(x) **Position, Position 2D**

Min(y) **Position, Position 2D**

Max(y) **Position, Position 2D**

Min(v) **Laser spot speed**

Max(v) **Laser spot speed**

Min(vx) **Velocity**

Max(vx) **Velocity**

Min(vy) **Velocity**

Max(vy) **Velocity**

Min(ax) **Acceleration**

Max(ax) **Acceleration**

Min(ay) **Acceleration**

Max(ay) **Acceleration**

Min(jx) **Jerk**

Max(jx) **Jerk**


Min(jy) **Jerk**

Max(jy) **Jerk**

Spot distance: NaN ("not a number") indicates that the [Simulation File](#) does not contain such data (prerequisite: in the [Simulation File](#), SpotDistance must have been defined as Active Channel).

2.5.6 Dialog “Loading Options”

The Dialog “Loading Options” opens, when you have selected a **Simulation File**, see Chapter 2.4 “Loading a Simulation File”, page 8.



Dialog “Loading Options”.

No reduction

Import option for the **Simulation File**: To load all **Simulation File** lines.

Reduction Tolerance

Performs data reduction during loading. The advantage is, that fewer position points are loaded and the display of the curve in the **syncAXIS control Viewer** is significantly faster when scrolling or zooming. The shape of the curve is preserved. In particular, all laser switching times and all sections in which a dynamic violation is present are not reduced.

Enter the reduction tolerance in mm (default is 0.01).

Show Laser Pre-Trigger

Shows the time shift of the laser signals by the argument `LaserPreTriggerTime`.

Show Laser Switch Offset

Shows the time shift of the laser signals by the argument `LaserSwitchOffsetTime`.

Data Cropping Options

Allows only certain sections to be imported. Select the section you want to import by entering the start and end values.

Load

Starts the import of the **Simulation File** according to the settings in the “Import Options” section.

Note: after the import process is completed, the status bar (see **Figure 1**, No. **10**) shows the settings most recently made in the “Import Options” dialog.

Append

This button is disabled immediately after starting the program. It is enabled after a **Simulation File** has been imported. Usage is as with **Load**. Difference: the selected **Simulation File(s)** are imported and shown *in addition* to the already imported ones.

Notes:


- The limits of the last loaded file are valid.
- If you use **Append** and select import options (see above) different to the already imported **Simulation File**, then the status bar (see **Figure 1**, No. **10**) even *only* displays the settings that has been most recently made in the “Import Options” section after the import process has been completed.

Cancel

To cancel a file import (starting from **Load**). Data loaded by then can still be displayed.

2.6 syncAXIS control Viewer Basic Procedure (Principle of Use)

Step	
(1) To start syncAXIS control Viewer.	<ul style="list-style-type: none"> Double-click <code>syncAXIScontrol_Viewer.exe</code>. syncAXIS control Viewer opens, see Figure 1.
(2) To set the import option and specify the desired simulation file(s).	<ol style="list-style-type: none"> In the main window, click File > Open. Navigate to the desired Simulation File and click Open. In the Dialog "Loading Options", set the desired option with which the Simulation File is to be imported. Then, click Load.
(3) To choose a diagram type (plot).	<ul style="list-style-type: none"> Click the desired diagram type (see page 15, for example, Position 2D).
(4) Optional: to show curve(s) of Active Channel in diagram (if applicable, these are shown in addition to other curves).	<ul style="list-style-type: none"> Select the desired check boxes (see page 15).
(5) To set which axes curves are to be shown in the diagram.	<ul style="list-style-type: none"> Click the desired option (see page 16, for example, X/Y).

Step (cont'd)	
(6) To set which motion portion(s) the curves shall show in the diagram.	<ul style="list-style-type: none"> Click the desired option (see page 16, for example, Combined).
(7) To choose a scan head (available on multi head systems).	<ul style="list-style-type: none"> Click the desired scan head number from the drop down list. (see page 16, for example, scan head 1).
(8) To set which vectors the curves shall show in the diagram.	<ul style="list-style-type: none"> Click the desired option (see page 16, for example, Show jumps for mark vectors and jump vectors; here, even color details are marked).
(9) Visual inspection of individual points in curves (in the diagram area).	<p>(1) Setup the Tracker according to your needs, see page 13.</p> <p>(2) Position the mouse pointer onto a curve in order to see details of this data point.</p>
(10) Visual inspection of extrema.	<ul style="list-style-type: none">  Caution! The accuracy of the shown values depend on the options you have selected for import. For exact results, you must use No reduction in step (2). Then, the status bar indicates "Selected import options: No Data Reduction". Check the values in the group for information display (see page 17) in regards to limit value exceedances of the utilized XL SCAN systems.
(11) Optional: Export of suitable settings.	<ul style="list-style-type: none"> Click File > Export Header(s) and choose the directory to save the XML file.

3 Change Index

The following are changes in this manual due to the technical evolution of the product as well as significant editorial changes.

Changes to document revision **1.5.0 en-US** from document revision 1.4.0 en-US

Where	What
Global	Document Revision <ul style="list-style-type: none"> • 1.5.0 en-US applies to <i>syncAXIS</i> control-software package <ul style="list-style-type: none"> • V1.8.0
Change Index, page 22	