



hurrySCAN, hurrySCAN II, SCANgine (7–14 mm) Standard Connector Positions and Pin-Outs

SL2-100 interface (separate connectors for data and power)




SL2-100 (9-pin female D-SUB connector)




* The 3.3 V voltage is supplied for SCANLAB's POF converter for optical data transmission (POF = Polymer Optical Fiber). This voltage should not be used for other purposes.


POWER IN (3-pin male D-SUB connector with high power contacts,




XY2-100 interface (common connector for data and power)




DIGITAL POWER IN (25-pin female D-SUB connector)




XY2-100 interface (separate connectors for data and power)



DIGITAL IN (25-pin female D-SUB connector)



POWER IN (9-pin male D-SUB connector)






hurrySCAN, hurrySCAN II, SCANgine (7–14 mm) Standard Connector Positions and Pin-Outs


XY2-100 interface (separate connectors for data, power and z-out)




DIGITAL IN (25-pin female D-SUB connector)




POWER IN (9-pin male D-SUB connector)




Z-OUT (15-pin female D-SUB connector)



Analog interface (separate connectors for data and power)



ANALOG IN (25-pin female D-SUB connector)



POWER IN (9-pin male D-SUB connector)

